



Assembly Instruction

SIRO-TV154-01



A: TV Stand x1



B: Legs x2



C: Bolt M8*35mm x6



D: Spring Washer M8*14 x6




E: Flat Washer M8*16 x6



F: Allen key M4 x1

STEP 1



FINISH

